



NOTES:

1. JUTE MESH - SHOULD BE USED ON SLOPES OF 3:1 OR STEEPER FOR STABILIZATION DURING CONSTRUCTION.
2. LOAM AND SEED SHALL NOT BE USED IN THE VEGETATED SWALE.
3. SCARIFY SUBGRADE TO A MIN. DEPTH OF 6" BEFORE INSTALLATION.



**Public Works Department
Engineering Division**

1 CITY HALL SQUARE, ROOM 710
BOSTON, MA 02201
(617) 635-4968

**VEGETATED SWALE
SECTION**

**DATE OF ISSUE:
DECEMBER 2024**

SCALE: N.T.S.

DETAIL NO.

G.322